



HUW1 Series

Intelligent Universal Circuit Breaker

Installation and Operation Instruction

Please read the instruction carefully before installing and using the product and keep it for future reference.

**HUANYU HIGH-TECH
CO., LTD.**

Attention:

After you receive the ordered products, please check according to the following terms:

- 1) Check whether the appearance, such as the housing, is damaged;
- 2) Check whether the attached accessories are complete according to the inventory of packing materials in Table 1;
- 3) Check whether the parameters on the label of the circuit breaker are consistent with the goods ordered.

Table 1 Inventory of packing materials

Name	Unit	Quantity	Notes
Circuit breaker	Set	1	Standard
HUW1 Series Intelligent Universal Circuit Breaker Instruction	Copy	1	Standard
Door frame+O-ring	Set	1	Standard
Phase spacer plate	Set	1	Standard
Screw	Bag	1	Standard (configured based on product specifications)
Desiccant	Bag	1	Standard
ST power module	Piece	1	Optional (only available when ordered)
ST201 relay module	Piece	1	Optional (only available when ordered)
Mechanical interlock	Set	1	Optional (only available when ordered)
Dual power controller	Set	1	Optional (only available when ordered)
ST-DP protocol conversion module	Piece	1	Optional (only available when ordered)
External transformer	Piece	1	Optional (only available when ordered)

The company pledges:

On the premise that users abide by the use and storage conditions and that the product seals are intact, if the product is damaged or cannot be used normally due to manufacturing quality problems within 18 months from the production date of the product, the company will be responsible for the repairing or replacement free of charge. If the warranty period expires, the users shall pay for the repair. However, if the damage is caused by the following circumstances, the fees for repair still shall be charged even within the warranty period:

- (1) Misuse, self-modification, improper maintenance, and other reasons;
- (2) Use beyond the standard specification requirements;
- (3) Falling, damage during transportation, or other causes after purchase;
- (4) Earthquake, fire, lightning stroke, abnormal voltage, other natural disasters and secondary disasters, etc.

In case of any questions, please contact the dealer or our customer service department.

Dear customers:

To protect our environment, please recycle the product or its components when the product is scrapped. For materials that cannot be recycled, please handle them properly. Thank you very much for your cooperation and support.



HUW1

Series Intelligent Universal Circuit Breaker

1 Scope of Application

The HUW1 Series Intelligent Universal Circuit Breaker (hereinafter referred to as “circuit breaker”) is suitable for distribution networks with AC 50 Hz, rated working voltage of 690 V and rated current up to 6,300 A, and is mainly used for power distribution, power feeding and power generation protection, so as to protect circuits and power equipment from faults such as overload, undervoltage, overvoltage, current voltage imbalance, short circuit and grounding fault. The rational operation of the power grid can be realized through load monitoring, regional interlock and other functions. Furthermore, the circuit breaker can also be used to measure power grid parameters such as current, voltage, power, frequency, electrical energy, demand and harmonics. It can also be directly used for overload, undervoltage and short-circuit protection of motors and generators.

The core component of circuit breakers adopt intelligent controllers, which can realize accurate selective protection, so as to avoid unnecessary blackout and enhance the reliability, continuity and safety of power supply. These components can also be equipped with open communication interfaces to realize telemetering, tele-signaling, telecontrol and teleregulation, thus meeting the requirements of the control center and the automation system.

The circuit breaker series can be used as isolators without intelligent controllers and transformers.


The circuit breaker series can be compatible with top-in or bottom-in incoming lines, which is suitable for various low-voltage power distribution fields such as power stations, factories and intelligent buildings, and can also be used for infrequent starting of motors.

The derivative products of this series of circuit breakers, HUW1PVA and HUW1F, have passed the ultra-high/-low temperature environment test and the "three prevention" related test, and are suitable for photovoltaic and wind power generation systems with AC 50 Hz, rated voltage up to 690 V and rated current up to 3,200 A. They are mainly used for power distribution, power feeding and power generation protection, so as to protect the lines and power supply equipment from faults such as overload, undervoltage, overvoltage, current voltage imbalance, short circuit and grounding fault.

The product complies with GB/T 14048.2 *Low-voltage Switchgear and Controlgear — Part 2: Circuit Breakers*.

2 Product Model Description and Classification

2.1 Product model description



2.2 Classification

2.2.1 According to the installation mode

Fixed, drawer.

2.2.2 According to the number of poles

Three-pole, four-pole.

2.2.3 According to the operation mode

Electrical operation, manual operation (for overhaul and maintenance).

2.2.4 Release type

Intelligent controller, undervoltage instantaneous (or delay) release and shunt strip.

2.2.5 According to the intelligent controller

Type L (DIP), Type M (digital) and Type H (liquid crystal).

2.2.6 According to the wiring mode

Horizontal wiring, vertical wiring.

3 Normal Working, Installation and Transportation Conditions

3.1 Normal working conditions

a) The ambient air temperature shall be -5°C to $+40^{\circ}\text{C}$ (-40°C to $+70^{\circ}\text{C}$ for HUW1F and HUW1PVA); and the average temperature within 24 hours shall not exceed $+35^{\circ}\text{C}$.

Note: If the upper limit exceeds $+40^{\circ}\text{C}$ or that the lower limit is lower than -5°C , the user shall consult with the manufacturer.

b) The altitude of the installation location shall not exceed 2,000 meters.

Note: If the circuit breaker is used at an altitude above 2,000 meters, the user shall consult with the manufacturer.

c) The relative atmospheric humidity does not exceed 50% when the ambient air temperature is $+40^{\circ}\text{C}$, and a higher relative humidity is allowed at a lower temperature. For example, when the average maximum relative

HUW1

Series Intelligent Universal Circuit Breaker

humidity in the wettest month is 90%, the average minimum temperature in this month is +20°C. Measures shall be taken to deal with the occasional condensation due to temperature changes.

d) The contamination grade is Grade 3.

e) The installation category of the main circuit of the circuit breaker is IV. When the rated working voltage of the main circuit is not greater than AC 400 V, the installation categories of the control circuit and the auxiliary circuit are III except that the undervoltage release coil and the primary coil of the power transformer of the intelligent controller are the same as the circuit breaker. When the rated working voltage of the main circuit is AC 400 V to AC 690 V, the control circuit and the auxiliary circuit need to be isolated from the main circuit by the transformer; the highest working voltage of the control circuit and the auxiliary circuit is AC 400 V; and the installation categories of the control circuit and the auxiliary circuit are both III.

f) The circuit breaker is suitable for electromagnetic environment A.

3.2 Normal installation conditions

a) Installation of the circuit breaker: Place the circuit breaker in the distribution cabinet and fasten it with four M8 (1,000 A shell frame) or M10 (2,000 A above shell frame) bolts and gaskets. The circuit breaker shall be installed smoothly without additional mechanical stress, so as to avoid damage to the circuit breaker or poor contact of the main busbar.

b) The circuit breaker shall be installed in places where there is no explosion hazard, conductive dust, metal corrosion, or insulation damage.

c) The protection level is IP20. When the circuit breaker is installed in the cabinet and the door frame is installed, the protection level can reach IP40.



3.3 Normal storage and transportation conditions

a) The lower temperature limit shall not be less than -25°C, and the upper temperature limit shall not be more than +55°C (while for HUW1F and HUW1PVA, the lower temperature limit shall not be less than -50°C, and the upper temperature limit shall not be more than +85°C). The relative humidity (at 25°C) shall not exceed 95%.

b) The product shall be handled with care during transportation, and shall not be turned upside down and rolled to avoid violent collision.

4 Product Structure and Working State

4.1 Product structure



HUW1

Series Intelligent Universal Circuit Breaker

4.2 Working state of the circuit breaker

4.2.1 Working state of the intelligent controller



Normal condition of the intelligent controller



When the intelligent controller is in the protection state, the circuit breaker is open. After clearing the line fault, press this button to close the circuit breaker.

4.2.2 Working state of the operating mechanism




Circuit breaker being open without stored energy



Circuit breaker being open with stored energy



Circuit breaker being closed without stored energy



Circuit breaker being closed with stored energy

4.2.3 Working state of the drawer seat (only available for the drawer mode circuit breaker)



Three-position lock of the drawer seat

Lock the main body of the circuit breaker in three positions, namely "Disconnection", "Test" and "Connection" of the drawer seat.



In the three positions of "Disconnection", "Test" and "Connection", the position lock is locked and the crank cannot be operated (in the unlocked state)

After the position lock is locked, press the position lock button to unlock (in the locked state) if the user needs to operate the crank again.

Three-position indicator of the drawer seat

Indicate the main body of the circuit breaker in three positions, namely "Disconnection", "Test" and "Connection" of the drawer seat.



In the "Disconnection" position, both the main circuit and the secondary circuit are disconnected



In the "Test" position, the main circuit is disconnected and the secondary circuit is connected



In the "Connection" position, both the main circuit and the secondary circuit are connected

HUW1

Series Intelligent Universal Circuit Breaker

5 Technical Parameters and Performance of the Circuit Breaker

5.1 Technical parameters and performance

Type and shell frame current I_{nm}	HUW1-1000	HUW1-2000 HUW1F-2000 HUW1PVA-2000	HUW1-3200 HUW1F-3200 HUW1PVA-3200	HUW1-4000	HUW1-6300	
Rated current I_n (A)	200, 400, 630, 800, 1,000	630, 800, 1,000, 1,250, 1,600, 2,000	2,000, 2,500, 2,900, 3,200	2,500, 2,900, 3,200, 4,000	4,000, 5,000, 6,300	
Neutral rated current I_N (A)	100% I_n	100% I_n	100% I_n	100% I_n	50% I_n	
Rated working voltage U_e (V)	AC 400/690					
Frequency	50 Hz					
Number of poles	3P/4P					
Rated impulse withstand voltage U_{imp} (kV)	AC 12					
Rated insulation voltage U_i (V)	AC 1,000					
Power frequency withstand voltage (V)	AC 3,500					
Rated ultimate short-circuit breaking capacity I_{cu} (kA)	AC 400 V	42	85	100	100	120
	AC 690 V	20	50	65	70	85
Rated operating short-circuit breaking capacity I_{cs} (kA)	AC 400 V	30	65	65	100	100
	AC 690 V	15	50	50	70	75
Rated short-time withstand capacity $I_{cw}/1_s$ (kA)	AC 400 V	30	65	65	100	100
	AC 690 V	15	50	65	70	85
Use category	B					
Full breaking time (without additional delay)	≤ 30 ms					
Closing time	≤ 70 ms					
Electrical life (times) $\leq 2,500$ 1 time/ 3 min $> 2,500$ 1 time/ 6 min	400V	15,000	8,000	6,000	5,000	3,500
	690V	6,000	6,000	5,000	3,500	2,000
Mechanical life (times) $\leq 2,500$ 1 time/ 3 min $> 2,500$ 1 time/ 6 min	Maintenance free	20,000	20,000	15,000	12,500	10,000
	With maintenance	30,000	30,000	25,000	20,000	20,000
Mechanical life of drawer seat (times) 1 time/2 min		1,000	1,000	1,000	600	300
Incoming mode	Top-in or bottom-in					
Flashover distance (mm)	0					
Mounting mode	Fixed or drawer				Drawer	
Wiring method	Horizontal or vertical			Horizontal		

Note: The mechanical life "1 Time" of drawer seat means that the circuit breaker body is moved from "Disconnection" to "Connection" and then to "Disconnection" position through cranking in the drawer seat.

HUW1

Series Intelligent Universal Circuit Breaker

5.2 Power consumption

Shell frame current (A)	Rated current (A)	Power consumption (W)			
		3P, drawer mode	4P, drawer mode	3P, fixed mode	4P, fixed mode
1,000	200	8	11	4	6
	400	35	47	18	24
	630	81	104	45	60
	800	96	128	48	64
	1,000	144	192	85	114
2,000	630	42	56	24	32
	800	67	90	38	51
	1,000	75	100	45	60
	1,250	117	156	70	94
	1,600	192	256	115	154
	2,000	276	368	156	208
3,200	2,000	276	368	156	208
	2,500	375	500	188	250
	2,900	454	606	252	336
	3,200	553	737	307	410
4,000	2,500	400	550	268	350
	2,900	510	680	275	380
	3,200	598	790	300	400
	4,000	660	880	332	450
6,300	4,000	576	768	-	-
	5,000	900	1,200	-	-
	6,300	1,429	1,905	-	-

Note: The power consumption of the circuit breaker refers to the power consumption of the main circuit measured by the rated current of the circuit breaker at normal temperature, excluding the power of other accessories with the power consumption of the circuit breaker. The data in this table is for users' selection reference only, and cannot be seen as the circuit breaker's actual power consumption when in use.

5.3 Altitude and derating factor

Altitude (m)		2,000	3,000	4,000	5,000
Derating factor of related items	Working current I_e	1	0.93	0.88	0.82
	Short-circuit breaking capacity I_{cu}, I_{cs}	1	0.83	0.71	0.63
	Short-circuit withstand capacity I_{cw}	1	0.83	0.71	0.63
	Rated impulse withstand voltage U_{imp}	1	0.9	0.71	0.63
	Power frequency withstand voltage	1	0.9	0.71	0.63
	Rated insulation voltage U_i	1	0.83	0.71	0.63

HUW1

Series Intelligent Universal Circuit Breaker

5.4 Look-up table of the working current derating with the ambient temperature change

Shell frame level (A)	Rated current (A)	Working current after derating (A)			
		+40°C	+50°C	+60°C	+70°C
1,000	200	200	200	200	200
	400	400	400	400	400
	630	630	630	630	630
	800	800	800	800	800
	1000	1000	850	850	800
2,000	630	630	630	630	630
	800	800	800	800	800
	1,000	1,000	1,000	1,000	1,000
	1,250	1,250	1,250	1,250	1,250
	1,600	1,600	1,600	1,600	1,600
	2,000	2,000	1,700	1,700	1,600
3200	2,000	2,000	2,000	2,000	2,000
	2,500	2,500	2,400	2,300	2,200
	2,900	2,900	2,900	2,900	2,900
	3,200	3,200	3,000	3,000	2,900
4,000	2,500	2,500	2,500	2,500	2,500
	2,900	2,900	2,900	2,900	2,900
	3,200	3,200	3,200	3,200	3,200
	4,000	4,000	3,800	3,600	3,600
6,300	4,000	4,000	4,000	4,000	4,000
	5,000	5,000	5,000	4,500	4,500
	6,300	6,300	5,500	5,500	5,000

5.5 Recommended look-up table corresponding to the cross-sectional area of the external copper busbar and the rated current of the circuit breaker

Rated current (A)	Specification of external copper busbar width×thickness (mm)	Number of wires per terminal (piece)	Cross-sectional area per terminal (mm ²)
200	20×5	1	100
400	40×5	1	200
630	40×5	2	400
800	50×5	2	500
1,000	60×5	2	600
1,250	80×5	2	800
1,600	100×5	2	1,000
2,000	100×5	3	1,500
2,500	100×5	4	2,000
2,900	100×10	3	3,000

HUW1

Series Intelligent Universal Circuit Breaker


Continued

Rated current (A)	Specification of external copper busbar width×thickness (mm)	Number of wires per terminal (piece)	Cross-sectional area per terminal (mm ²)
3,200	100×10	4	4,000
3,600	100×10	5	5,000
4,000	100×10	5	5,000
5,000	100×10	6	6,000
6,300	100×10	8	8,000

Note: The material of the external copper busbar in this table is T2 bare copper. The specifications of the external copper busbar can be changed according to the actual usage, but it shall meet the cross-sectional area requirements of different currents in the table. Also, the sum of the contacting areas between copper busbars shall not be less than the cross-sectional area so as to ensure good contact.

6 Protection Characteristics of the Intelligent Controller

6.1 Type and interface description of 1,000 A shell frame intelligent controller



Type L4 (DIP)

Type 2M (digital display)

Type 3H (liquid crystal)

6.1.1 Interface symbols, indicator lights and key descriptions of 1,000 A shell frame L3/L4 (DIP) intelligent controller

Serial number	Symbol/Name	Definition
1	Reset button	After the release is interrupted due to the circuit breaker fault, it is required to press this button before the circuit breaker can be closed again.
2	In	Circuit breaker rated current
3	"40–100" indicator light	This group of lights is a load current indicator, which shows the percentage of the load current to the setting current (I_{r1}). If the percentage exceeds 100%, the overload light will be on.
4	" I_g , I_i , I_{sd} , I_R " fault indicator light	When there is a ground fault, the I_g light is on; when there is an overload fault, the I_R light is on; and when there is a short-circuit fault, the I_{sd} light is on for the short-delay action of the circuit breaker and the I_i light is on for the instantaneous action.
5	Time setting value comparison table	Comparison table of action delay time values of grounding protection, short-circuit short time delay protection and overload long time delay protection.
6	Current setting value comparison table	Comparison table of current multiples of grounding protection, short-circuit instantaneous protection, short-circuit short time delay protection and overload long time delay protection.

HUW1

Series Intelligent Universal Circuit Breaker

Continued










Serial number	Symbol/Name	Definition
7	"t _R " DIP switch	Setting of the delay time value corresponding to the overload long time delay protection action
8	"I _R " DIP switch	Setting of the overload long time delay protection current multiple
9	"I _{sd} " DIP switch	Setting of the short-circuit short time delay protection current multiple
10	"I _i " DIP switch	Setting of the short-circuit instantaneous protection current multiple
11	"I _g " DIP switch	Setting of the grounding protection current multiple
12	"t _g " DIP switch	Setting of the delay time value corresponding to the grounding protection action
13	"MCU" indicator light	During normal operation, the MCU light is normally on, and goes out during self-diagnosis and power failures.
14	"Fault Check" key	Press this button to display the previous line fault protection section of the system memory.
15	"Test" key	During normal operation, press the test button, and the controller will send out instantaneous trip signals to test the action performance of the circuit breaker
16	"Clear Light" key	After the test trip, phase current selection, fault check and fault trip, press the clear light key to restore the controller to a normal working state.
17	"t _{sd} " DIP switch	Setting of the delay time value corresponding to the short-circuit short time delay protection action

6.1.2 Interface symbols, indicator lights and key descriptions of 1,000 A shell frame 2M (digital) intelligent controller


Serial number	Symbol/Name	Definition
1	Reset button	After the release is interrupted due to the circuit breaker fault, it is required to press this button before the circuit breaker can be closed again
2	In	Circuit breaker rated current
3	L ₁ , L ₂ , L ₃ , N indicators	During normal operation, L ₁ , L ₂ , L ₃ and N-phase (i.e. A, B, C and N-phase) current indicators flash cyclically
4	Digital display window	Parameters such as current, voltage, frequency, setting and fault are displayed in the window
5	Indicator lights of corresponding parameters	I _{c1} indicates load monitoring 1 protection; I _{c2} indicates load monitoring 2 protection; δ indicates current imbalance protection; I _g indicates grounding protection; L indicates long time delay protection; S indicates short time delay protection; I indicates instantaneous protection; T indicates the self-diagnosis fault status indication; ×10/1 indicates the number of circuit breaker actions; % indicates the contact wear percentage; A/kA indicates ampere/kiloampere (current); S indicates second (time)
6	"Enter" key	Press "Enter" to enter the functional state or save the changed data
7	▼ key	Press ▼ to select function items or reduce parameter values
8	"Setting" indicator light	When the "Setting" light is always on, you can view or modify the setting values of various protection characteristic parameters
9	"Inquiry" indicator light	When the "Inquiry" light is always on, you can view the fault history
10	"Alarm" indicator light	When the "Alarm" light is always on, it indicates being in the process of fault delay
11	"Fault" indicator light	When the "Fault" light is always on, it indicates the fault category, and circularly displays the fault current and duration
12	▲ key	Press ▲ to select function items or increase parameter values
13	"Back" key	Press "Back" to return to the previous operation
14	"Test" indicator light	When the "Test" light is always on, the trip test can be carried out
15	"Save" indicator light	When the "Save" light flashes, it indicates a data change

Series Intelligent Universal Circuit Breaker

6.1.3 Interface symbols, indicator lights and key descriptions of 1,000 A shell frame 3H (liquid crystal) intelligent controller

Serial number	Symbol/Name	Definition
1	"Reset" button	After the release is interrupted due to the circuit breaker fault, it is required to press this button before the circuit breaker can be closed again
2	In	Circuit breaker rated current
3	Liquid crystal display (LCD)	Display all measurement parameters, system setting parameters, protection setting parameters and all information in Chinese
4	Overload and short-circuit protection area	When the current protection is set, the indicator light of this area is always on, indicating that the protection current value or delay time value of the corresponding area is being set;
5	Grounding protection area	In case of fault or alarm, the indicator light of this area flashes, indicating that the corresponding area is in fault protection or alarm;
6	 "System Settings" key	Quickly switch to the "System Settings" main menu ("Right Arrow" when adjusting the system clock)
7	 "Running Parameters" key	Quickly switch to the "Running Parameters" main menu ("Left Arrow" when adjusting the system clock)
8	 "Up Arrow" key	Move the cursor up, change the selected parameter up, or position the display to the left
9	 "Down Arrow" key	Move the cursor down, change the selected parameter down, or position the display to the right
10	 "Exit" key	Exit the current menu to enter the previous menu, or cancel the modification of the current parameters
11	 "Reset" key	Reset to enter the initial working state in a fault trip or an alarm state
12	"Fault/Alarm" indicator light	During normal operation, the fault or alarm indicator light is not on; When the "Fault/Alarm" indicator light flashes, there must be a fault in the system.
13	"Normal" indicator light	When the controller is powered on, the "Normal" indicator light shall always flash. If the light does not turn on after power-on, the controller is not working properly and shall be replaced immediately.
14	"Communication" indicator light	The communication indicator light is on, indicating that communication data is transmitted; the light goes off when there is no communication data transmission.
15	 "Protection Settings" key	Quickly switch to the "Protection Settings" main menu
16	 "Information Inquiry" key	Quickly switch to the "Information Inquiry" main menu
17	 "Enter" key	Enter the next menu of the item pointed by the current cursor, select the current parameter, or save the modification
18	Test interface	It includes the following functions: DC 24 V power input port; analog signal input port; programming and communication interface

6.2 Type and interface description of 2,000 A (and above) shell frame intelligent controller



HUW1

Series Intelligent Universal Circuit Breaker

6.2.1 Interface symbols, indicator lights and key descriptions of 2,000 A (and above) shell frame L3/L4 (DIP) intelligent controller










Serial number	Symbol/Name	Definition
1	Reset button	After the release is interrupted due to the circuit breaker fault, it is required to press this button before the circuit breaker can be closed again
2	In	Circuit breaker rated current
3	"40–100" indicator light	This group of lights is a load current indicator, which shows the percentage of the load current to the setting current (I_{r1}). If the percentage exceeds 100%, the overload light will be on.
4	" I_{r4} , I_{r1} , I_{r2} , I_{r3} " DIP switch	Setting of the asymmetric grounding (neutral connection) fault, overload long time delay, short-circuit short time delay, and short-circuit instantaneous rated current multiples respectively
5	"Fault Display" area indicator light	Indicate the fault category (corresponding to indicator light is on): I_{r4} indicates grounding fault, I_{r1} indicates long time delay fault, I_{r2} indicates short time delay fault, I_{r3} indicates instantaneous short circuit fault
6	" t_G , t_L , t_S " DIP switch	Setting of the action time of the asymmetric grounding (neutral connection) fault, overload long time delay and short time delay. See the corresponding table under the DIP switch for the setting time
7	"Fault Check" key	Press this button to display the previous line fault protection section of the system memory
8	"Select" key	Press this key to cyclically display L_1 , L_2 and L_3 phase currents or fault check status to cyclically display the fault current or the time value
9	"Test" key	During normal operation, press the test button, and the controller will send out instantaneous trip signals to test the action performance of the circuit breaker
10	"Clear Light" key	After the test trip, phase current selection, fault check and fault trip, press the clear light key to restore the controller to a normal working state
11	"Overload" indicator light	When the light is on, it means that the load current has exceeded the overload long time delay protection current value, and the overload long time delay starts to delay the action or the alarm
12	"Phase Current" indicator light	Display L_1 , L_2 and L_3 phase currents, and show the phase with the largest current during the operation
13	"MCU" indicator light	During normal operation, the MCU light is normally on, and goes out during self-diagnosis and power failures

6.2.2 Interface symbols, indicator lights and key descriptions of 2,000 A (and above) shell frame 2M (digital) intelligent controller

Serial number	Symbol/Name	Definition
1	Reset button	After the release is interrupted due to the circuit breaker fault, it is required to press this button before the circuit breaker can be closed again
2	In	Circuit breaker rated current
3	Digital display window	Parameters such as current, voltage, frequency, setting and fault are displayed in the window
4	"Test" indicator light	Display when setting the test trip and no trip (corresponding to the test area)
5	"Fault Display" area indicator light	I_{r4} indicates grounding current, I_{r1} indicates long time delay current, I_{r2} indicates short time delay current, I_{r3} indicates instantaneous current, time setting and fault display
6	"Load 1, Load 2" indicator light	Load Monitoring 1 & Load Monitoring 2 current setting and alarm indicator light
7	"Setting" key	Select keys for setting parameters (current and time) of the items such as grounding, long time delay and short time delay
8	"Trip" key	Check whether the opening function of the intelligent controller is normal (the circuit breaker is closed first) or not
9	"No Trip" key	Check whether the intelligent controller's "Alarm Only Without Opening" function is normal (the circuit breaker is closed first) or not
10	"Save" key	After setting the parameters, press the "Save" key to save them
11	Power interface	DC 24 V power input port;
12	"+/-" key	When adjusting parameters, press the "+" key for increasing and the "-" key for decreasing
13	"Fault Check" key	Press this button to display the previous line fault protection section of the system memory
14	"Display Check" key	Press "Clear Light" and then the "Display Check" key for three seconds to turn on all lights and digital tubes, then release the key to turn off all lights
15	"Clear Light" key	After the test trip, phase current selection, fault check and fault trip, press the clear light key to restore the controller to a normal working state
16	"Select" key	Press this key to cyclically display L_1 , L_2 and L_3 phase currents or fault check status to cyclically display the fault current or the time value
17	"G, L_1 , L_2 , L_3 , MAX" indicator lights	Four-phase, grounding and maximum phase current indicator lights, corresponding to the maximum current phase and MAX indicator light
18	"A, kA, s" indicator light	Current and time unit indicator light, where A indicates ampere (long time delay and short time delay), kA indicates kiloampere (instantaneous), and s indicates second

Series Intelligent Universal Circuit Breaker

6.2.3 Interface symbols, indicator lights and key descriptions of 2,000 A (and above) shell frame 3H (liquid crystal) intelligent controller

Serial number	Symbol/Name	Definition
1	Reset button	After the release is interrupted due to the circuit breaker fault, it is required to press this button before the circuit breaker can be closed again
2	In	Circuit breaker rated current
3	Liquid crystal display (LCD)	Display all measurement parameters, system setting parameters, protection setting parameters and all information in Chinese
4	Overload and short-circuit protection area	When the current protection is set, the indicator light of this area is always on, indicating that the protection current value or delay time value of the corresponding area is being set;
5	Grounding protection area	In case of fault or alarm, the indicator light of this area flashes, indicating that the corresponding area is in fault protection or alarm;
6	 "System Settings" key	Quickly switch to the "System Settings" main menu ("Right Arrow" when adjusting the system clock)
7	 "Running Parameters" key	Quickly switch to the "Running Parameters" main menu ("Left Arrow" when adjusting the system clock)
8	 "Up Arrow" key	Move the cursor up, change the selected parameter up, or position the display to the left
9	 "Down Arrow" key	Move the cursor down, change the selected parameter down, or position the display to the right
10	 "Exit" key	Exit the current menu to enter the previous menu, or cancel the modification of the current parameters
11	Test interface	It has three functions: DC 24 V power input port, analog signal input port, programming and communication interface
12	 "Enter" key	Enter the next menu of the item pointed by the current cursor, select the current parameter, or save the modification
13	 "Information Inquiry" key	Quickly switch to the "Information Inquiry" main menu
14	 "Protection Settings" key	Quickly switch to the "Protection Settings" main menu
15	"Communication" indicator light	The communication indicator light is on, indicating that communication data is transmitted; the light goes off when there is no communication data transmission.
16	"Normal" indicator light	After the controller is powered on, the "Normal" indicator light keeps flashing. If the light does not turn on after power-on, the intelligent controller is not working properly and shall be replaced immediately.
17	"Fault/Alarm" indicator light	During normal operation, the fault or alarm indicator light is not on; when the "Fault/Alarm" indicator light flashes, there must be a fault in the system.
18	 "Reset" key	Reset to enter the reset (running) state in a fault trip or an alarm state

Note: Due to the rapid upgrade of the intelligent controller, its physical interface may be different from the existing instruction. Please refer to the physical object.

6.3 Function configuration table of the intelligent controller

Controller type	DIP type (L)	Digital type (M)	Liquid crystal type (M, H)	
Standard functions	<ul style="list-style-type: none"> Long time delay protection Short-circuit instantaneous protection Parameter setting Indicator light display Fault self-diagnosis Fault memory Thermal memory Test trip 	<ul style="list-style-type: none"> Long time delay protection Short time delay protection Short-circuit instantaneous protection Grounding protection (vector sum type) Parameter setting Digital display Test trip Effective value protection Test function Fault memory Fault self-diagnosis Thermal memory More protection functions, including six optional characteristic curves Contact wear and mechanical life indication Load monitoring (Mode I) 	<ul style="list-style-type: none"> Short-circuit instantaneous protection Short time delay fixed time protection Multi-curve short time delay inverse time protection Multi-curve long time delay protection Current imbalance protection Grounding protection (vector sum type) Neutral phase protection Disconnection self-diagnosis Load monitoring (Mode I) Undervoltage protection Overvoltage protection Voltage imbalance protection Communication function (Type H) Thermal memory Three-/four-phase current Asymmetric grounding current Long time delay heat capacity Phase & Line voltage Voltage imbalance 	<ul style="list-style-type: none"> Frequency Phase sequence Power Power factor Current waveform Harmonic influence coefficient of power grid Chinese graphic liquid crystal display LED status indication Keyboard operation Eight fault records Eight alarm records Eight shift records Main contact wear equivalent Number of operations Number of trips System clock Test & Lock Fault self-diagnosis
Optional functions	<ul style="list-style-type: none"> Short time delay protection Grounding protection (vector sum type) Alarm signal output 	<ul style="list-style-type: none"> Contact output of four groups of signals MCR and HSISC protection Menu functions Measurement: Voltage, frequency, power factor, active power, active watt hour Power grid parameter history recording 	<ul style="list-style-type: none"> Output of four groups of contacts Leakage protection (with special transformer) <p>Note: No grounding protection is required when provided with leakage protection</p> <ul style="list-style-type: none"> Demand value measurement and protection Temperature control monitoring and protection Zone selective interlock 	<ul style="list-style-type: none"> Overfrequency protection Phase sequence protection Reverse power protection Reclosing Underfrequency protection MCR and HSISC protection

HUW1

Series Intelligent Universal Circuit Breaker

6.4 Protection characteristics of the intelligent controller

6.4.1 Long time delay protection and curve

The long overload delay protection function is generally used to protect the cable from the overload based on the true RMS of the current.

The long-delay action current is continuously adjustable, and the tripping time is of inverse time characteristic. The adjustment step of the short-time key is 1A (2A for 2,000 A above).

Distribution protection current set value I_r		(0.4–1.0) I_n +OFF										Current tolerance		±10%			
Generator protection current set value I_r		(0.4–1.25) I_n +OFF															
Applied current I										Agreed tripping time							
1.05 I_r										>2h No trip							
1.3 I_r										<1h Trip							
Type of protection characteristics	Fault current	Setting time T_r (s)															
SI Standard inverse time lag	1.5 I_r	0.61	0.98	1.47	2.46	3.68	4.91	6.14	9.21	11.05	17.19	24.56	36.84	49.13	61.41	73.69	85.97
	2 I_r	0.36	0.57	0.86	1.43	2.15	2.87	3.58	5.37	6.45	10.03	14.33	21.49	28.65	35.82	42.98	50.15
	6 I_r	0.14	0.22	0.33	0.55	0.82	1.1	1.37	2.06	2.47	3.84	5.48	8.22	10.96	13.7	16.45	19.19
	7.2 I_r	0.12	0.2	0.3	0.5	0.74	0.99	1.24	1.86	2.23	3.48	4.97	7.45	9.93	12.42	14.9	17.38
VI Very inverse time lag	1.5 I_r	2	3.2	4.8	8	12	16	20	27	36.6	56	80	120	160	200	240	280
	2 I_r	1	1.6	2.4	4	6	8	10	13.5	18	28	40	60	80	100	120	140
	6 I_r	0.2	0.32	0.48	0.8	1.2	1.6	2	2.7	3.6	5.6	8	12	16	20	24	28
	7.2 I_r	0.16	0.26	0.39	0.65	0.97	1.29	1.61	2.18	2.9	4.52	6.45	9.68	12.9	16.13	19.35	22.58
EI (G) Extreme inverse time lag (for general distribution protection)	1.5 I_r	8	12.8	19.2	32	48	64	80	108	144	224	320	480	640	800	960	1000
	2 I_r	3.33	5.33	8	13.33	20	26.67	33.33	45	60	93.33	133.33	200	266.67	333.33	400	433.33
	6 I_r	0.29	0.46	0.69	1.14	1.71	2.29	2.86	3.86	5.14	8	11.43	17.14	22.86	28.57	34.29	37.14
	7.2 I_r	0.2	0.31	0.47	0.79	1.18	1.57	1.97	2.66	3.58	5.51	7.87	11.8	15.74	19.67	23.6	25.57
EI (M) Extreme inverse time lag (for motor protection)	1.5 I_r	6.22	9.96	14.93	24.89	37.34	49.78	62.23	84.01	112.01	174.24	248.91	373.37	497.82	622.28	746.73	208.96
	2 I_r	2.95	4.72	7.07	11.79	17.69	23.58	29.48	39.79	53.06	82.53	117.9	176.86	235.81	294.76	353.71	383.19
	6 I_r	0.28	0.45	0.68	1.13	1.69	2.26	2.82	3.81	5.08	7.9	11.29	16.94	22.58	28.23	33.88	36.7
	7.2 I_r	0.2	0.31	0.47	0.78	1.17	1.56	1.95	2.63	3.51	5.46	7.8	11.7	15.61	19.51	23.41	25.36
HV High voltage fuse compatibility	1.5 I_r	2.46	3.94	5.91	9.85	14.77	19.69	24.62	33.23	44.31	68.92	98.46	147.69	196.92	246.15	295.38	320
	2 I_r	0.67	1.07	1.6	2.67	4	5.33	6.67	9	12	18.67	26.67	40	53.33	66.67	80	86.67
	6 I_r	0.01	0.01	0.02	0.03	0.05	0.06	0.08	0.1	0.14	0.22	0.31	0.46	0.62	0.77	0.93	1
	7.2 I_r	0	0.01	0.01	0.01	0.02	0.03	0.04	0.05	0.07	0.1	0.15	0.22	0.3	0.37	0.45	0.48
I^2T Universal inverse time protection	1.5 I_r	15	30	60	120	240	360	480	600	720	840	960					
	2 I_r	8.44	16.88	33.75	67.5	135	202.5	270	337.5	405	472.5	540					
	6 I_r	0.94	1.88	3.75	7.5	15	22.5	30	37.5	45	52.5	60					
	7.2 I_r	0.65	1.3	2.6	5.21	10.42	15.63	20.83	26.04	31.25	36.46	41.67					

Note 1: This table takes the set value of the long time delay action duration of the LCD intelligent controller as an example.

Note 2: Action time error ±15%

Series Intelligent Universal Circuit Breaker

6.4.2 Thermal memory protection

Repeated overload may cause the conductor to heat up. The intelligent controller has the function of simulating the heating effect of the bimetallic strip after the action of the fault delay such as overload or short time delay.

Setting time for heat capacity cooling: Instantaneous, 10 min, 20 min, 30 min, 1 h, 2 h, 3 h, OFF

Note: Power failure of the intelligent controller can eliminate thermal memory protection.

6.4.3 Short-circuit short time delay protection and curve

Short time delay protection prevents the impedance short circuit of the distribution system. This kind of short circuit is usually caused by the local short circuit fault of the line, and the current generally exceeds the overload range, but the short-circuit current is not very large.

The trip delay of short-circuit short time delay is to realize selective protection.

Short-circuit delay protection is based on the true RMS of the current, which can be divided into inverse time period and fixed time period; and further strengthen the cooperation with the lower protection device.

Short time delay protection can be provided with zone selective interlock function.

Action current set value I_{sd}	(1.5–15) I_r +OFF	Current tolerance	±10%
Inverse time delay action time T_{sd}	The curve is the same as the overload long time delay curve, and the curve speed is 10 times faster than the overload long time delay curve (the time calculated by the overload delay time curve formula divided by 10 is the short time delay inverse time delay time)		
Fixed time delay set value T_{sd}	0.1 s – 1 s (differential: 0.1 s)		

Note: When both inverse time protection and fixed time protection are on, the set value of the inverse time current must be less than that of the fixed time current, otherwise the inverse time function will automatically fail. Also, the actual inverse time delay time shall not be less than the setting time of the fixed time limit.

6.4.4 Short-circuit instantaneous protection and curve

The instantaneous protection function prevents the load short circuit of the distribution system. This short circuit is usually an interphase fault, with a large short-circuit current, which needs to be quickly disconnected. This protection is based on the true RMS of the current.

Action current set value I_i	(1.0–20) I_r +OFF	Current tolerance	±10%
Action characteristics	≤0.85 I_i No action		
	>1.15 I_i Action		

Note 1: The protection parameters shall not be cross-set, and shall comply with $I_r < I_{sd} < I_i$.

Note 2: The maximum instantaneous action current of HUW1-6300 is set as 100 kA.

6.4.5 Grounding protection and curve

There are two protection modes for the ground fault caused by equipment insulation damage, including residual current (difference) type (T) and ground current type (W). The T-type detection of the zero sequence current, that is, the vector sum of four-phase (three-phase, four-wire system) or three-phase (three-phase, three-wire system) current is taken for protection. The ground current directly detects the current on the grounding cable through a special external transformer, which can simultaneously protect the upper and lower ground faults of the circuit breaker.

Action current set value I_g	(0.2–1.0) I_n + OFF	Current tolerance	± 10%
Action characteristics	<0.8 I_g No action		
	≥1.1 I_g Action		
Action time T_g Time tolerance ±10%	Fixed time setting	0.1–1s+OFF	
	Inverse time shear coefficient C_r	1.5–6 + OFF	
	Inverse time formula	$t = T_g \times C_r \times I_g / I$	t — delay time I_g — set action current T_g — set delay time I — ground fault current C_r — shear coefficient


Note 1: When the multiple of the fault current (I/I_g) is less than C_r , the action is of inverse time characteristic; when the multiple of the fault current is greater than or equal to C_r , the action is of fixed time characteristic.

Note 2: The functions of grounding alarm and grounding protection are independent of each other, with independent parameter settings, which can coexist.

HUW1

Series Intelligent Universal Circuit Breaker


Ground fault protection mode and electrical schematic diagram



Mode 1 (difference type)

TN-C, TN-C-S and TN-S distribution systems use three-pole circuit breakers without neutral current transformers.


- The vector sum of the three-phase current is taken for the ground fault protection signal.
- The protection characteristics are fixed time or inverse time protection.



Mode II (difference type)

The four-pole circuit breaker with built-in neutral current transformer is used in the TN-S distribution system.

- The vector sum of the four-phase current is taken for the ground fault protection signal.
- The protection characteristics are fixed time or inverse time protection.




Mode III (difference type)

The three-pole circuit breaker with external neutral current transformer is used in the TN-S distribution system.

- The vector sum of the three-phase current and the N-phase current is taken for the ground fault protection signal.
- The protection characteristics are fixed time or inverse time protection.

Note: The conductor length of the neutral current transformer is not more than 2 meters.



Mode IV (ground current type)

The three-pole circuit breaker with external ground current transformer is used in the ground current protection distribution system.

- Provided with additional special current transformer.
- The distance between the special current transformer and the circuit breaker is not more than 10 meters.

6.4.6 Neutral line protection

The cable and current characteristics used in the neutral phase are often quite different from those of other three phases, and intelligent controllers implement different protections for the neutral phase according to different applications. When the neutral line is thin, it can be protected by semi-fixed value method; when the neutral line is the same as other phases, it can be protected by full fixed value; and when the harmonics in the power grid are serious, double fixed value or 1.6 times fixed value can be used for protection.

Action current set value I_N	(0.5, 1.0) I_n + OFF	Current tolerance	±10%
Action time T_N	Same as overload long time delay duration		

6.4.7 Current imbalance protection

The current imbalance protection protects the open-phase and three-phase current imbalance, and performs protection actions according to the imbalance rate between the three-phase currents. When the execution mode is "Alarm", its action principle is the same as that of grounding protection.

HUW1

Series Intelligent Universal Circuit Breaker

Protection set value	5% – 60% (step length: 1%)
Delay time	0.1 s – 40 s (step length: 0.1 s)
Protection return set value	5% – starting value (step:1%)
Delay time	10s – 200s
No action characteristics	≤ 0.9 (actual current imbalance rate/set value), no action
Action characteristics	> 1.1 (actual current imbalance rate/set value), action

6.4.8 Load monitoring

Load monitoring can be used for pre-alarm and branch load control. The action principle is based on the power or current monitoring, with two optional modes.

Mode I: The load of two branches can be independently controlled. When the operating parameters exceed the setting value, the corresponding load monitors the DO delay action (corresponding DO function needs to be set), and controls the load of two branches to be interrupted to ensure the power supply of the main system.

Mode II: Generally, it is used to control the load of the same branch. When the operating parameters exceed the starting value, the "Load Monitoring I" DO delays the action (the action form can be pulse mode or level mode) to interrupt the branch load. If the operating parameter value is lower than the return value after the interruption, and after the delay set time, the "Load Monitoring I" DO returns, and the "Load Monitoring II" DO acts to connect the interrupted load and restore the power supply of the system.

Unloading I action settings	Current mode 1/2	Setting current I_{C1}, I_{C2}	$(0.2 - 1) I_r$
	Power mode 1/2	Setting power P_{C1}, P_{C2}	200 kW – 10,000 kW
Unloading I delay settings	Current mode 1/2	Current delay time T_{C1}, T_{C2}	$(20\% - 80\%) T_r$
	Power mode 1/2	Power delay time T_{C1}, T_{C2}	10 s–3,600 s
Unloading II action settings	Current mode 1	Setting current I_{C1} (starting value)	$(0.2 - 1) I_r$
	Current mode 2	Setting current I_{C2} (return value)	$0.2I_r - I_{C1}$
	Power mode 1	Setting power P_{C1} (starting value)	200 kW–10,000 kW
	Power mode 2	Setting power P_{C2} (return value)	100 kW– P_{C1}
Unloading II delay settings	Current mode 1	Current delay time T_{C1}	$(20\% - 80\%) T_r$
	Current mode 2	Current delay time T_{C2}	10 s–600 s
	Power mode 1/2	Power delay time T_{C1}, T_{C2}	10 s–3,600 s
Protection alarm DO output		Set one DO of the signal unit to "Load Monitoring I" and another to "Load Monitoring II".	

Note: In Mode II, $I_{C1} \geq I_{C2}$ or $P_{C1} \geq P_{C2}$ is required.


6.4.9 Residual current (leakage) protection

It is suitable for the leakage fault caused by equipment insulation damage or human contact with exposed conductive parts, and the residual current set value $1\Delta n$ is irrelevant to the rated current of the circuit breaker. The signal sampling mode is zero sequence sampling, and a rectangular transformer is required. This sampling has high accuracy and sensitivity, which is suitable for the protection of the small current.

Action current set value $1\Delta n$	0.5A–30A+OFF				Current tolerance				$\pm 10\%$				
Action characteristics	$< 0.8I\Delta n$, no action												
	$\geq 1.01I\Delta n$, action												
Delay time setting $T\Delta n$ (s)	Instantaneous	0.06	0.08	0.17	0.25	0.33	0.42	0.5	0.58	0.67	0.75	0.83	
Maximum breaking time of fault current (s)	$I\Delta n$	0.04	0.36	0.5	1	1.5	2	2.5	3	3.5	4	4.5	5
	$2I\Delta n$	0.04	0.18	0.25	0.5	0.75	1	1.25	1.5	1.75	2	2.25	2.5
	$5I\Delta n, 10I\Delta n$	0.04	0.07	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1

HUW1

Series Intelligent Universal Circuit Breaker



RCD: Zero sequence current transformer
R: Ground resistor

Electrical diagram of residual current protection

6.4.10 Overvoltage protection

The intelligent controller measures the effective value of the primary circuit voltage. When all three phase-to-phase voltages (line voltages) are greater than the set value, that is, when the minimum value of the three line voltages is greater than the set value of the overvoltage protection, the overvoltage protection acts; when the minimum value of the three line voltages is less than the return value, the alarm action returns.

Action threshold (V)	Return threshold – 1,200 (step length: 1)	
Action delay time (s)	0.2–60 (step length: 0.1)	
Return threshold (V)	100–action threshold (step length: 1)	This set value is only available when the execution mode is "Alarm", and the starting value must be greater than or equal to the return value.
Return delay time (s)	0.2 – 60 (step length: 0.1)	
Action or alarm characteristics (delay tolerance±10%)	$U_{min}/\text{action threshold} \geq 1.1$ Fixed time action or alarm	
	$U_{min}/\text{action threshold} < 0.9$ No action or alarm	
Overvoltage alarm return characteristics (delay tolerance±10%)	$U_{max}/\text{action threshold} \leq 0.9$ Return	
	$U_{max}/\text{action threshold} > 1.1$ No return	
Alarm contact output	When the execution mode is "Alarm", the "Overvoltage Alarm" contact output can be added	

6.4.11 Voltage imbalance protection

Voltage imbalance rate protection acts according to the imbalance rate between three line voltages. The intelligent controller measures the voltage imbalance rate, and performs protection action when the voltage imbalance rate is greater than the action threshold; when the voltage imbalance rate is less than the return threshold, the alarm action returns.

Action threshold	2% – 30% (differential: 1%)	
Action delay time (s)	0.2 – 60 (differential: 0.1)	
Return threshold	2% – Starting value (differential: 1%)	This set value is only available when the execution mode is "Alarm", and the return value must be less than or equal to the starting value.
Return delay time (s)	0.2 – 60 (differential: 0.1)	
Action or alarm characteristics (delay tolerance±10%)	Actual voltage imbalance rate/set value ≥ 1.1 Fixed time action or alarm	
	Actual voltage imbalance rate/set value < 0.9 No action or alarm	
Voltage imbalance alarm return characteristics (delay tolerance±10%)	Actual voltage imbalance rate/set value ≤ 0.9 Return	
	Actual voltage imbalance rate/set value > 1.1 No return	
Alarm contact output	When the execution mode is "Alarm", the "Voltage Imbalance Alarm" contact output can be added	

6.4.12 Phase sequence protection

Phase sequence detection is taken from the primary voltage. When it is detected that the phase sequence is the same as the setting direction of the starting value, the protection action is instantaneous. When one or more phases of voltage do not exist, this function will automatically exit.

Setting range of action phase sequence	$\Delta\phi$: A, B, C/ $\Delta\phi$: A, C, B
Alarm contact output	When the execution mode is "Alarm", the "Phase Sequence Fault Alarm" contact output can be added
Protection execution mode	Alarm/trip/shutdown

HUW1

Series Intelligent Universal Circuit Breaker

6.4.13 Undervoltage protection

The intelligent controller measures the true RMS of the primary circuit voltage. When all three phase-to-phase voltages (line voltages) are less than the set value, that is, when the maximum value of three line voltages is less than the set value of the undervoltage protection, the undervoltage protection acts; when the maximum value of three line voltages is greater than the return value, the alarm action returns.

Action threshold (V)	100–return threshold (step length: 1)		
Action delay time (s)	0.2–60 (step length: 0.1)		
Return threshold (V)	Action threshold – 1,200 (step length: 1)	This set value is only available when the execution mode is "Alarm", and the return value must be greater than or equal to the starting value.	
Action delay time (s)	0.2–60 (step length: 0.1)		
Action or alarm characteristics (delay tolerance±10%)	U _{max} /action threshold ≤0.9	Fixed time action	
	U _{max} /action threshold >1.1	No action	
Undervoltage alarm return characteristics (delay tolerance±10%)	U _{min} /action threshold >1.1	Fixed time return	
	U _{min} /action threshold ≤0.9	No return	
Alarm contact output	When the execution mode is "Alarm", the "Undervoltage Alarm" contact output can be added		

6.4.14 Demand current protection

Calculate the demand value of the true RMS of each phase current in a sliding time window, and perform protection action when the demand value exceeds the limit. When the execution mode is "Alarm", its action principle is the same as that of grounding alarm. The setting of the sliding time window is in the menu item "Meter Settings" (the parameters are set in the same way for phases A, B, C and N).

Protection starting set value (A)	(0.2–1.0) I _n		
Action delay time set value (s)	15–1,500		
Protection action return set value (A)	0.2 I _n –starting set value	This set value is only available when the execution mode is "Alarm".	
Protection return delay time (s)	15–3,000 s		
Demand current action characteristics (delay tolerance±10%)	I/Starting set value ≤0.9	No action	
	I/Starting set value >1.1	Fixed time action	
Demand current return characteristics (delay tolerance±10%)	I/Return set value >1.1	No return	
	I/Return set value ≤0.9	Fixed time return	
Protection execution mode	Alarm/trip/shutdown		

6.4.15 Underfrequency & Overfrequency protection

The intelligent controller detects the frequency of the system voltage, and can perform protection if the frequency is too high or too low. The action principle and characteristics of overfrequency and underfrequency protection are the same as those of overvoltage and undervoltage protection.

Setting range of different parameters	Action threshold	Underfrequency	45 – return value (step length: 0.5 Hz)		
		Overfrequency	Return value – 65 Hz (step length: 0.5 Hz)		
	Action delay time	0.2–5.0 s (step length: 0.1 s)			
	Return threshold	Underfrequency	Starting value – 65 Hz	This set value is only available when the execution mode is "Alarm"	
		Overfrequency	45 Hz – starting value		
Return delay time	0.2 – 36.0 s (step length: 0.1 s)				
Alarm contact output	When the execution mode is "Alarm", the "Underfrequency Alarm" and "Overfrequency Alarm" contact output can be added				
Protection execution mode	Alarm/trip/shutdown				

HUW1

Series Intelligent Universal Circuit Breaker

6.4.16 Reverse power protection

The sum of three-phase active power is taken for the inverse power protection. When the direction of power flow is opposite to that of the user's setting power and greater than the set value, the protection starts. The direction of power and the incoming direction of power supply are set in the "Meter Settings" menu, which must be consistent with the actual application. Its action principle is the same as overvoltage protection.

Protection starting set value	5–500 kW	
Protection action delay time set value	0.2–20 s	
Protection action return set value	5 kW – starting set value	This set value is only available when the execution mode is "Alarm", and the return value must be greater than or equal to the starting value.
Protection return delay time	1.0–360 s	
Protection alarm DO output	Set one DO of the signal unit to "Power Failure".	
Protection execution mode	Alarm/trip/shutdown	

6.4.17 MCR and HSISC protection

MCR and HSISC are instantaneous protection for the adjustment of the circuit breaker itself. When the out-of-limit fault current generates, the intelligent controller will issue a trip instruction within 10 ms. Among them, MCR protects the switch-on ability of the circuit breaker to prevent the switch from being damaged due to the switch-on current exceeding the switch-on limit ability, and the protection works at the moment of opening and closing of the circuit breaker (within 100 ms). HSISC protects the maximum carrying capacity of the circuit breaker to prevent the switch from carrying the current exceeding the maximum breaking capacity, which will take effect after closing for 100 ms.

MCR, HSISC action current set value (kA)	30 –100	
No action characteristics	$< 0.80I_i$	No action
Action characteristics	$> 1.0I_i$	Action
Action delay	$< 20\text{ms}$	

Note: This group of set values is generally set according to the breaking capacity of the circuit breaker when the circuit breaker leaves the factory, and is not adjustable by the end user.

Factory default MCR: HUW1-1000/20 kA; HUW1-2000 above /50 kA.

HSISC: HUW1-1000/30kA; HUW1-2000/50kA; HUW1-3200/65kA; HUW1-4000/80kA; HUW1-6300/100kA.

6.4.18 Self-diagnosis

The intelligent controller can diagnose its own faults, including ultra-high ambient temperature, error of E₂PROM data, error of A/D sampling, and circuit breaker failing to act.

6.4.19 Contact wear indication

The intelligent controller can display the current contact wear on the screen. When the intelligent controller leaves the factory, the display value is 100%, which means that the contact is not worn. When the display value drops to 60%, an alarm signal will be sent to remind the user to take maintenance measures timely. After the contact is replaced, it can be restored to the initial wear value through setup.

6.4.20 Test & Lock

There are three test modes for test tripping, namely three-section protection, grounding/leakage fault and mechanism action time.

Three-section protection test: Input the fault current to simulate the protection of the controller when the overload, short circuit or transient fault occurs.

Grounding/leakage fault test: Input the grounding/leakage fault current to simulate the protection of the controller when the grounding/leakage fault occurs.

Mechanism action time test: Force the magnetic flux converter to act to test the inherent mechanical time of circuit breaker tripping.

6.4.21 Zone selective interlock


In the same power circuit, two or more circuit breakers with superior-subordinate relationship can realize zone selective interlock, which includes short-circuit interlock and grounding interlock. There are two possibilities for this interlock according to the location of the fault.

1. When the location of the short circuit or ground fault is at the outgoing side of the subordinate circuit breaker (2#–4# circuit breaker), such as location ②, the subordinate circuit breaker trips instantaneously and sends a regional interlock signal to the superior circuit breaker; the superior circuit breaker (1# circuit breaker) receives the regional interlock trip signal and delays according to the short circuit or grounding protection settings. If the fault current is eliminated during the delay of the superior circuit breaker, the protection will return and the superior circuit breaker will not act; if the fault current of the subordinate circuit breaker is still not eliminated after tripping, the superior circuit breaker will act according to the short-circuit or grounding protection setting to cut off the fault line.

Series Intelligent Universal Circuit Breaker

2. When the location of the short circuit or ground fault is between the superior circuit breaker (1# circuit breaker) and the subordinate circuit breaker (2#–4# circuit breaker), such as location ①, the superior circuit breaker does not receive the regional interlock signal. Therefore, it trips instantly and quickly cuts off the faulty line.

I/O port setting requirements of the circuit breaker: At least one DI of the superior circuit breaker is set as the regional interlock detection; and at least one DO of the subordinate circuit breaker is set as the regional interlock signal output.



6.4.22 Reclosing

The reclosing function means that the circuit breaker is disconnected due to undervoltage or power failure under non-fault conditions; and when the power supply system returns to normal, the product will automatically close to keep the power supply. The circuit breaker is suitable for places that are not easy to maintain, and can be used in lightning-prone areas or power grids with unstable power supply to prevent the circuit breaker from tripping due to short-time voltage drop, based on the protection caused by abnormal line voltage.


6.4.23 Communication

Through the communication interface, the intelligent controller can realize data transmission functions such as telemetering, telecontrol, teleregulation and telesignaling according to the specified protocol. The output of the communication interface adopts photoelectric isolation, which is suitable for the environment where strong electromagnetic interferences.

Communication protocol	Modbus-RTU	Profibus-DP	DeviceNet
Communication address	0–255	3–126	0–63
Transmission rate (bit/s)	9.6k, 19.2k	Self-adaption	125k, 250k, 500k
Communication module	Internal		External
Network function	Telemetering	Remote real-time monitoring of the current, voltage, fundamental current, fundamental voltage, power, power factor, electrical energy, frequency, harmonic content for current and voltage, total harmonic distortion of voltage and current, etc.	
	Teleregulation	Remote reading and modification for protection parameters	
	Telecontrol	Remote control of opening/closing of the circuit breaker	
	Telesignaling	Alarm, fault trip, stored energy signal, undervoltage, breaker body position, closing readiness, opening/closing position and other indicators of the breaker status.	

HUW1

Series Intelligent Universal Circuit Breaker



Note: 32 communicable circuit breakers can be connected on one line at the same time. The maximum wiring distance is 1,200 meters, and the communication distance can be extended by installing intermediate relays.

6.4.24 Busbar temperature detection and protection

The busbar temperature protection function is realized by external temperature acquisition module or built-in temperature sensor. The temperature acquisition module can monitor the temperature of 8 busbars at the same time, and the built-in temperature sensor monitors the temperature of the conductive busbars in the circuit breaker body.

Through RS-485 communication mode, the intelligent controller can read the busbar temperature data of the temperature acquisition module in real time, calculate and process the data according to the preset protection parameters, and realize the functions of busbar overtemperature tripping and overtemperature alarm.

Parameter setting

Temperature protection function on/off: ON/OFF

Overtemperature protection action temperature: 100–160°C

Overtemperature protection action delay time: 0.2 s–60 s

Overtemperature alarm temperature: 100–160°C

Overtemperature alarm delay time: 0.2 s–60 s

6.5 Intelligent controller factory default settings

Long time delay I_l : $1 I_n$, $T_r = 19.2$ s (C03), curve EI (G);

Inverse time short delay I_s : $4 I_r$, $T_s = 0.1 T_r$; Fixed time short delay I_{sd} : $8 I_r$, $T_{sd} = 0.4$ s

Instantaneous I_i : $12 I_n$; Grounding I_g : OFF (open the default value $I_g = I_n$, inverse time shear coefficient $k =$ OFF, $T_g = 0.4$ s)

Note: The default value is set as the liquid crystal type, and the setting values will be different for other different types.

HUW1

Series Intelligent Universal Circuit Breaker

6.6 Main parameter settings of the intelligent controller

6.6.1 Test trip setting (taking 2M type as an example)

Example: Test trip setting with short time delay

Note: 1. Reset the "Reset" button after the test, otherwise the circuit breaker cannot be closed
2. Press the "Clear Light" key to exit the setting menu

Press the "Set" key to enter the setting menu, and then continue to press the key until the I_{r2} indicator light and "kA" light are on, and the digital display screen displays "6,400 (default value)"

After closing the circuit breaker, press the "Trip" key, then the switch trips after 0.4s delay, and the reset button pops up at the same time



6.6.2 Long time delay setting current settings (taking 2M type as an example)

Example: Set the rated current of the circuit breaker from 1,600 A to 800 A

Press the "Set" key to enter the setting menu, and then continue to press the key until the I_{r1} indicator light and "A" light are on, and the digital display screen displays "1,600"

Press the "-" key to turn down the current value

Adjust the current to "800"

Then press the "Save" key to save the settings

Note: Press the "Clear Light" key to exit the setting menu after setting

6.6.3 Reclosing settings (additional for 3H type)

1) Start reclosing setting

Current protection Load monitoring Voltage protection Other protection	Execution mode = Reclosing Starting value = 280 V	Starting time = 0.0 s Return Value = 360	Return time = 10 s	Note: When the measured line voltage is lower than the starting value of 280 V, i.e. the action voltage, the intelligent controller will send the opening signal with a delay of 0.0 s to make the shunt strip act; when the voltage is restored to the return value of 360 V and kept for 10.0 s, the intelligent controller sends a pulse signal to the closing electromagnet to make it act, thus completing the automatic reclosing.
---	--	---	-----------------------	--

Press to enter the menu
Press to select "Voltage Protection"
Press to enter the modification

Press to select the modification, and to enter the modification, and then press to adjust the value, and to save

2) Reclosing I/O settings

Clock settings Meter settings Test & Lock Communication settings I/O settings	Function settings = DO3 = Undervoltage opening	Function settings = DO4 = Undervoltage reclosing	Execution mode = DO3 = Open pulse = 1s	Execution mode = DO4 = Open pulse = 1s
---	--	--	---	---

Press to enter the menu
Press to select "I/O Settings"
Press to enter the modification

Press to select the modification, and to enter the modification, and then press to adjust the value, and to save

Note: In the actual operation of the intelligent control interface, there may be some differences with the operation instruction due to different controller types and upgrade versions. You can operate according to the prompts of the intelligent controller operation interface, or consult the manufacturer.

HUW1


Series Intelligent Universal Circuit Breaker

7 Wiring Diagrams of the Circuit Breaker Control Circuit

7.1 Wiring diagram of the control circuit of the HUW1-1000 Circuit Breaker

- 1) The circuit on the dotted line is wired by the user, which cannot be performed when the optional accessories are not customized.
- 2) The accessories such as intelligent controller, undervoltage release, shunt strip, closing electromagnet and electric operating mechanism shall be connected to different power sources respectively when the voltages are different.
- 3) Undervoltage release can be directly connected to the power supply of the main circuit, with the highest working voltage not exceeding its rated working voltage; when the working voltage of the main circuit exceeds its rated working voltage, it needs to be isolated from the main circuit by a transformer.
- 4) The three-position indication function of the drawer seat is only optional for the drawer mode circuit breaker.

Wiring diagram of the secondary circuit of the HUW1-1000 L3/L4, 2M Intelligent Controller



Terminal functions in the wiring diagram of the secondary circuit of HUW1-1000 L3/L4, 2M Intelligent Controller

Terminal number	Function description	Notes
1, 2	Auxiliary power input: AC 230 V, AC 400 V, DC 220 V, DC 110 V	Power module is required for DC power
3, 4, 5	Fault trip auxiliary contact, contact capacity: AC 250 V, 3 A	
8, 9	External transformer	Optional accessories
20, 21	Undervoltage release	Optional accessories
22, 23	Shunt strip	Optional accessories
24, 25	Closed electromagnet	
26, 27, 28	Electric operating mechanism, 28 connected to the green line, 27 connected to the red line and 26 connected to the black line	
29-40	DF auxiliary switch	


Interpretation of symbols in the wiring diagram

HUW1: HUW1-1000 Universal Circuit Breaker S1 – S4: Signal lamp (user-provided) TA: Current transformer
 SAL: Microswitch SB1: Opening button (user-provided) SB2: Close button (user-provided) X: Closed electromagnet F: Shunt strip
 Q: Undervoltage release (optional) M: Electric operating mechanism SA: Limit switch L (+), N (-): Control power supply (DC: L is positive; N is negative) A, B, C, N: Main circuit phase line DF: Auxiliary switch

HUW1

Series Intelligent Universal Circuit Breaker

Wiring diagram of the secondary circuit of the HUW1-1000 3H Intelligent Controller



Terminal functions in the wiring diagram of the secondary circuit of the HUW1-1000 3H and Reclosing Intelligent Controller


Terminal number	Function description	Notes
1, 2	Auxiliary power input: AC 230 V, AC 400 V, DC 220 V, DC 110 V	Power module is required for DC power
3, 4, 5	Fault trip auxiliary contact, contact capacity: AC 250 V, 3 A	
6, 7	Communication interface output, 6 connected to A (red line), 7 connected to B	Default Modbus-RTU
8–15	Signal output; 8 and 9: DO1; 10 and 11: DO2; 12 and 13: DO3; 14 and 15: DO4	Set based on functional requirements
16, 17, 18, 19	Voltage signal measurement: 16 connected to N, 17 connected to A, 18 connected to B, 19 connected to C	Optional functions
20, 21	Undervoltage release	Optional accessories
22, 23	Shunt strip	
24, 25	Closed electromagnet	
26, 27, 28	Electric operating mechanism, 28 connected to the green line, 27 connected to the red line and 26 connected to the black line	
29–40	DF auxiliary switch terminal	

Note: When the external transformer needs to be configured, the terminal numbers are 8 and 9, and the signal output has no DO1 (optional functions, which shall be noted when ordering).

HUW1

Series Intelligent Universal Circuit Breaker

Wiring diagram of the secondary circuit of the HUW1-1000 Reclosing Intelligent Controller



Interpretation of symbols in the wiring diagram

- HUW1: HUW1-1000 Universal Circuit Breaker
- S1–S4: Signal lamp (user-provided)
- TA: Current transformer
- SAL: Microswitch
- SB1: Opening button (user-provided)
- SB2: Close button (user-provided)
- X: Closed electromagnet
- F: Shunt strip
- Q: Undervoltage release (optional)
- M: Electric operating mechanism
- SA: Limit switch
- L (+), N (-): Control power supply (DC: L is positive; N is negative)
- A, B, C, N: Main circuit phase line
- DF: Auxiliary switch
- Protocol converter: Other protocols except Modbus-RTU protocol need to be configured
- SB3: Anti-reopening button (for reclosing maintenance)
- SB4: Anti-reclosing button (for reclosing maintenance)

Series Intelligent Universal Circuit Breaker

7.2 Wiring diagram of the control circuit of the HUW1-2000 (and above) Circuit Breakers

1) The circuit on the dotted line is wired by the user, which cannot be performed when the optional accessories are not customized.


2) The accessories such as intelligent controller, undervoltage release, shunt strip, closing electromagnet and electric operating mechanism shall be connected to different power sources respectively when the voltages are different.

3) Undervoltage release must be directly connected to the power supply of the main circuit, with the highest working voltage not exceeding its rated working voltage. When the working voltage of the main circuit exceeds its rated working voltage, it needs to be isolated from the main circuit by a transformer.

4) The three-position indication function of the drawer seat is only optional for the drawer circuit breaker.

Note: For the wiring type of independent six normally open and six normally closed of auxiliary switch, perform wiring adjustment at the space according to the user's order function requirements.

Wiring diagram of the secondary circuit of the HUW1-2000 (and above) L3/L4, 2M/3M Intelligent Controller



Wiring type of auxiliary switch
(default: Conversion 4 NO & 4 NC)

Conversion 4 NO & 4 NC

36 38 39 41 42 44 45 47



37 40 43 46

Conversion 6 NO & 6 NC

36 38 39 41 42 44 45 47 50 52 53



50 52 53

Conversion 4 NO & 4 NC

36 38 39 41 42 44 45 47



37 39 41 43 45 47

Independent 5 NO & 5 NC

36 38 39 41 42 44 45 47 50 52 53



37 39 41 43 45 47

Conversion 6 NO & 6 NC

36 38 39 41 42 44 45 47 50 52 53



50 52 53

HUW1

Series Intelligent Universal Circuit Breaker

Terminal functions in the wiring diagram of the secondary circuit of the HUW1-2000 (and above) L3/L4, 2M Intelligent Controller

Terminal number	Function description	Notes
1, 2	Auxiliary power input: AC 230 V, AC 400 V, DC 220 V, DC 110 V	
3, 4, 5	Fault trip auxiliary contact, contact capacity: AC 250 V, 3 A	
6, 7	Circuit breaker status auxiliary contact (normally closed), contact capacity: AC 250 V, 3 A	
8, 9	Circuit breaker status auxiliary contact (normally open), contact capacity: AC 250 V, 3 A	
20	Grounding (PE)	
21, 22, 23, 24	Voltage signal measurement: 21 connected to N, 22 connected to A, 23 connected to B, 24 connected to C	Optional functions
25, 26	External transformer input (leakage and neutral transformer)	Optional functions
27, 28	Undervoltage release	Optional accessories
29, 30	Shunt strip	
31, 32	Closed electromagnet	
33, 34, 35	Electric operating mechanism, 35 connected to the green line, 34 connected to the black line and 33 connected to the red line	
36-...	DF1 auxiliary switch terminal	

Terminal functions in the wiring diagram of secondary circuit of HUW1-2000 (and above) 3M/3H and Reclosing Intelligent Controller

Terminal number	Function description	Notes
1, 2	Auxiliary power input: AC 230 V, AC 400 V, DC 220 V, DC 110 V	
3, 4, 5	Fault trip auxiliary contact, contact capacity: AC 250 V, 3 A	
6, 7	Circuit breaker status auxiliary contact (normally closed), contact capacity: AC 250 V, 3 A	
8, 9	Circuit breaker status auxiliary contact (normally open), contact capacity: AC 250 V, 3 A	
10, 11	Communication interface output, 10 connected to A, 11 connected to B	Default Modbus
12-19	Signal output; 12 and 13: DO1; 14 and 15: DO2; 16 and 17: DO3; 18 and 19: DO4	Set based on functional requirements
20	Grounding (PE)	
21, 22, 23, 24	Voltage signal measurement: 21 connected to N, 22 connected to A, 23 connected to B, 24 connected to C	
25, 26	External transformer input	
27, 28	Undervoltage release	Optional accessories
29, 30	Shunt strip	
31, 32	Closed electromagnet	
33, 34, 35	Electric operating mechanism, 35 connected to the green line, 34 connected to the black line and 33 connected to the red line	
36-...	DF1 auxiliary switch terminal	

Interpretation of symbols in the wiring diagram


Symbols	Interpretation	Notes
HUW1	HUW1 Universal Circuit Breaker	
S1 -S7	Signal lamp	User-provided
TA	Current transformer	
SAL	Microswitch	
SB1	Opening button	User-provided
SB2	Close button	User-provided
X	Closed electromagnet	
F	Shunt strip	
Q	Undervoltage release	Optional accessories
M	Electric operating mechanism	
SA	Electric operating mechanism limit switch	

Symbols	Interpretation	Notes
PE	Grounding wire	
L (+), N (-)	Control power supply (DC: L is positive; N is negative)	
A, B, C, N	Main circuit phase line	
DF1	Auxiliary switch	Type optional
DF2	Drawer-type three-position electric indicator switch	Optional accessories
ST power module	DC 24 V power supply is provided	Optional accessories
ST201	Relay module	Optional accessories
Protocol converter	Except Modbus protocol, other protocols need to be configured	Optional accessories

HUW1

Series Intelligent Universal Circuit Breaker


Wiring diagram of the secondary circuit of the HUW1-2000 (and above) 2H/3H Intelligent Controller



HUW1

Series Intelligent Universal Circuit Breaker

Wiring diagram of the secondary circuit of the HUW1-2000 (and above) Reclosing Intelligent Controller



Note: When the switch at the bottom left of the controller is placed in the "I" position, the automatic reclosing function is turned on; when the switch is placed in the "O" position, the automatic reclosing function is turned off (anti-reclosing for maintenance).

Series Intelligent Universal Circuit Breaker

8 Dual Power Controller

8.1 Operation interface and symbol meaning of the dual power controller

Dual power controller interface



Key description

Name of key	Manual operation mode	Automatic operation mode
Auto/Manual	Selection key of manual operation mode	Selection key of automatic operation mode
OFF/ESC	Disconnection	Escape key
N/+	Common	+ (Up) key
R/-	Standby	- (Down) key
↵		Confirm (select) key
Reset	Controller reset	Controller reset


Indicator light description

Name	Definition	Notes
N (up)	ON: The common voltage is abnormal	
	OFF: The common voltage is normal	
R (up)	ON: The standby voltage is abnormal	
	OFF: The standby voltage is normal	
N (down)	ON: The dual power switch is in the common power supply position	N & R OFF: The dual power switch is in the off position
	OFF: The dual power switch is not in the common power supply position	
R (down)	ON: The dual power switch is in the standby power supply position	
	OFF: The dual power switch is not in the standby power supply position	

Indicator light description

Name	Definition
Run	Flash: The controller is running
	Normally On or Off: The controller is in a fault state
Alarm	ON: The dual power supply has alarm information
	OFF: The dual power supply has no alarm information
Auto	ON: The dual power switch works in automatic operation mode
	OFF: The dual power switch works in manual operation mode
Fire	Fire control signal indicator light

8.2 Outline and installation dimensions of the dual power controller



Panel opening dimension

Note: When installing, put the dual power controller into the opening of the panel, and clamp the controller on the panel with four clips.


Important reminder: To ensure the normal operation of dual power supply products and prevent operation errors, the dual power controller products need to be equipped with corresponding mechanical interlock devices.

HUW1

Series Intelligent Universal Circuit Breaker

8.3 Wiring diagrams of the dual power controller

8.3.1 Wiring diagram of the HUW1-1000 Dual Power Controller



Terminal interpretation of dual power controller

Terminal number	Interpretation	Terminal number of the circuit breaker
1-4	Connected to the main circuit, 1 to U_A , 2 to U_B , 3 to U_C and 4 to U_N	Connected to the main circuit incoming side by the users themselves
5	Control power output (L)	1, 27
6	Control power output (N)	2, 22, 24, 26
7	Signal output DO1, connected to the closed electromagnet	25
8	Signal output DO2, connected to the shunt strip	23
9		Standby
10	Signal input DI1,	31
11	Signal input DI2,	4
12	Signal input DIV-,	5, 30

Note 1: The dotted line refers to an external connection; except for 1-4# terminals which are connected to the incoming side of the main circuit, users only need to insert X1 and X2 plugs for other terminals.

Note 2: The common power supply and standby power supply are connected in the same way, just with the wires plugged into their corresponding ports.


Note 3: The working power supply of accessories can only be AC 230 V, which is powered by a dual power controller without external power supply.

Note 4: The generator starting signal control terminals DO5B, COM (normally closed) or DO5A, COM (normally open) are wired by the users themselves.

HUW1

Series Intelligent Universal Circuit Breaker

8.3.2 Wiring diagram of the HUW1-2000 (and above) Dual Power Controller



Terminal interpretation of the dual power controller

Terminal number	Interpretation	Terminal number of the circuit breaker
1-4	Connected to the main circuit, 1 to UA, 2 to UB, 3 to UC and 4 to UN	Connected to the main circuit incoming side by the users themselves
5	Control power output (L)	1, 33
6	Control power output (N)	2, 30, 32, 34
7	Signal output DO1, connected to the closed electromagnet	31
8	Signal output DO2, connected to the shunt strip	29
9		Standby
10	Signal input DI1,	8
11	Signal input DI2,	4
12	Signal input DIV-,	5, 9

Note 1: The dotted line refers to an external connection; except for 1-4# terminals which are connected to the incoming side of the main circuit, users only need to insert X1 and X2 plugs for other terminals.

Note 2: The common power supply and standby power supply are connected in the same way, just with the wires plugged into their corresponding ports.

Note 3: The working electric source of accessories can only be AC 230 V, which is powered by a dual power controller without external power supply.


Note 4: The generator starting signal control terminals DO5B, COM (normally closed) or DO5A, COM (normally open) are wired by the users themselves.

HUW1

Series Intelligent Universal Circuit Breaker

8.4 Meanings of operation interface and symbols of the dual power bus coupler controller

Dual power bus coupler controller interface



Dual power bus coupler controller key

Keys	Meaning of setting state	Meaning of browsing state
	Select setting items or change parameters	Scroll to view browsing items
	Select setting items or change parameters	Scroll to view browsing items
	Enter the parameter change and confirm the change	No definition
	1. Switch the manual and automatic modes 2. Combine with the [Browse] key to enter the settings	No definition
	Select single digits, deciles and percentiles when modifying numerical parameters	Enter the browsing state
	Return to the previous level or exit the setting	Exit the browsing state

Manual operation key



Circuit I breaker closing
Contact breaker opening
Circuit II breaker opening




Circuit I breaker closing
Contact breaker opening
Circuit II breaker opening




Circuit I breaker closing
Contact breaker opening
Circuit II breaker opening



Circuit I breaker closing
Contact breaker opening
Circuit II breaker opening



Circuit I breaker closing
Contact breaker opening
Circuit II breaker opening





Circuit I breaker closing
Contact breaker opening
Circuit II breaker opening

Controller status display

Settings 1, 2, 3, 4 — Setting 1: User primary settings; Setting 2: User advanced settings; Settings 3, 4: Factory settings;
I, II — I: Display Circuit I parameters; II: Display Circuit II parameters;
ABC — A: Display Phase A parameters; B: Display Phase B parameters; C: Display Phase C parameters;
Power generation — "Power Generation" is displayed after the generator is started, and "Power Generation" flashes when the generator is delayed to stop;
S V Hz — Display parameter units, which respectively indicate seconds, volts and hertz;
8888 — Digital tube; small digital tube displays setting items, and large digital tube displays parameters;
Automatic — The controller is in automatic working mode;
Manual — The controller is in manual mode;

Automatic recovery — The controller is in the automatic charge and automatic recovery mode;
Mutual backup — The controller is in the automatic charge without automatic recovery mode;
Circuit I — Circuit I commonly used;
Circuit II — Circuit II commonly used;
Grid/Grid — Applicable power grid structure of the controller: Power grid — Power grid;
Grid/Generator — Applicable power grid structure of the controller: Power grid — Generator;
Alarm — Prompt an alarm;
Fire protection — Fire signal input is available.


8.5 Outline and installation dimensions of the dual power bus coupler controller




Panel opening dimension

8.6 Wiring diagrams of the dual power bus coupler controller

8.6.1 Wiring diagram of the HUW1-1000 Dual Power Bus Coupler Controller



Dual power terminal panel




Supplementary explanation

35, 36	Fire signal input (default 24 V/AC, DC)
37	Programmable relay 2
38	
39	Programmable relay 1
40	
41	Auxiliary source (24-36 V, AC/DC)
42	
43, 44	Communication 485 A
45	Communication 485B
46	

Note 1: The generator starting signal control terminals 37, 38 (normally closed) or 38, 39 (normally open) are wired by users themselves;
 Note 2: If the closing electrical interlock is required, an interlock auxiliary switch shall be connected in series between the closing output of the controller and the closing electromagnet of the circuit breaker. The circuit on the dotted line is wired by the user.

Closing electrical interlock




Interpretation of symbols: 1QF indicates Circuit I breaker; 2QF indicates Circuit II breaker; 3QF indicates bus tie breaker; F indicates shunt strip; X indicates closed electromagnet.
 Note: Box I, II and III contain the terminal numbers of the circuit breaker secondary circuit, those outside the box are the corresponding terminal numbers of the dual power bus coupler controller, and those outside the box are the user connections.
 Important reminder: To ensure the normal operation of dual power supply products and prevent operation errors, the dual power controller products need to be equipped with corresponding mechanical interlock devices.



HUW1

Series Intelligent Universal Circuit Breaker

8.6.2 Wiring diagram of the HUW1-2000 (and above) Dual Power Bus Coupler Controller



Note 1: The generator starting signal control terminals 37, 38 (normally closed) or 38, 39 (normally open) are wired by users themselves;
Note 2: If the closing electrical interlock is required, an interlock auxiliary switch shall be connected in series between the closing output of the controller and the closing electromagnet of the circuit breaker. The circuit on the dotted line is wired by the user.




Interpretation of symbols: 1QF indicates Circuit I breaker; 2QF indicates Circuit II breaker; 3QF indicates bus tie breaker; F indicates shunt strip; X indicates closed electromagnet.
Note: Box I, II and III contain the terminal numbers of the circuit breaker secondary circuit, those outside the box are the corresponding terminal numbers of the dual power bus coupler controller, and those outside the box are the user connections.
Important reminder: To ensure the normal operation of dual power supply products and prevent operation errors, the dual power controller products need to be equipped with corresponding mechanical interlock devices.

HUW1


Series Intelligent Universal Circuit Breaker

9 Outline and Installation Dimensions of the Circuit Breaker (Unit: mm)

9.1 Outline and installation dimensions of the HUW1-1000 Fixed Circuit Breaker





9.2 Outline and installation dimensions of the HUW1-1000 Drawer Mode Circuit Breaker





HUW1

Series Intelligent Universal Circuit Breaker

9.3 Outline and installation dimensions of the HUW1-2000 Fixed Circuit Breaker




In (A)	a (mm)
630, 800	10
1,000, 1,250, 1,600	15
2,000	20





Horizontal extended busbar wiring (special supply)

Circuit breaker installation bottom surface





K-direction horizontal wiring and installation dimensions

9.4 Outline and installation dimensions of the HUW1-2000 Drawer Mode Circuit Breaker




In (A)	a (mm)
630, 800	10
1,000, 1,250, 1,600	15
2,000	20



Horizontal extended busbar wiring (special supply)

Circuit breaker installation bottom surface




K-direction horizontal wiring and installation dimensions


HUW1

Series Intelligent Universal Circuit Breaker

9.5 Outline and installation dimensions of HUW1F-2000 and HUW1PVA-2000 Fixed Circuit Breakers




9.6 Outline and installation dimensions of HUW1F-2000 and HUW1PVA-2000 Drawer Circuit Breakers




HUW1

Series Intelligent Universal Circuit Breaker

9.7 Outline and installation dimensions of the HUW1-3200 Fixed Circuit Breaker




9.8 Outline and installation dimensions of the HUW1-3200 Drawer Circuit Breaker




HUW1

Series Intelligent Universal Circuit Breaker

9.11 Outline and installation dimensions of the HUW1-4000 Fixed Circuit Breaker




9.12 Outline and installation dimensions of the HUW1-4000 Drawer Circuit Breaker




HUW1

Series Intelligent Universal Circuit Breaker

9.13 Outline and installation dimensions of the HUW1-6300 Drawer Circuit Breaker (In = 4,000, 5,000)



9.14 Outline and installation dimensions of the HUW1-6300 Drawer Circuit Breaker (In = 6,300)



HUW1

Series Intelligent Universal Circuit Breaker

10 Circuit Breaker Installation Operation

10.1 Proper placement after unpacking

- Place the box correctly according to the instruction of the packing box, and screw out the self-tapping screw at the lower terminal of the outer box to remove the box.
- The circuit breaker can be removed after the bolt fixing the circuit breaker is screwed out. For the circuit breaker fixed in the drawer seat, the main body of the circuit breaker shall be moved out of the drawer seat through cranking, and then the bolt for fixing the drawer seat can be screwed out to remove the drawer seat.
- The removed circuit breaker shall be placed correctly as shown in the figure to avoid damaging the circuit breaker.



Wrong placement



Correct placement

10.2 Circuit breaker pre-installation inspection

- Check whether the parameters on the label of the circuit breaker are consistent with the good ordered.
- Before installation, it shall be confirmed that the control power supply voltage is consistent with the circuit breaker accessory voltage.
- Before installing the circuit breaker, check the insulation resistance of the circuit breaker with a 1,000 V megger, which shall not be less than 20 $\mu\Omega$ when the ambient temperature is 20°C±5°C and the relative humidity is 50%-70%. Otherwise, it shall be dried to make the insulation resistance meet the requirements before use.

The test locations of the insulation resistance are between phases as well as between phases and frames when the circuit breaker is closed; and between the incoming and outgoing lines of each phase when the circuit breaker is disconnected.

10.3 Installation of circuit breaker

- Mode I for the installation of the drawer circuit breaker: Move the circuit breaker body out of the drawer seat through cranking, install the inner bottom plate of the drawer seat (inner installation size) on the guide rail of the distribution cabinet, and fasten it with four M10 bolts and gaskets with tightening torque of (15 – 20) N.m or (30 – 36) N.m.
- Mode II for the installation of the drawer circuit breaker: Instead of moving the circuit breaker body out of the drawer seat, directly install the supports (external installation size) on both sides of the circuit breaker on the guide rail of the distribution cabinet, and fasten them with four M10 bolts and gaskets with tightening torque of (15 – 20) N.m or (30 – 36) N.m.
- The installation of the fixed circuit breaker is the same as the installation mode II of the drawer circuit breaker.

10.4 Busbar installation and wiring of circuit breaker

- When installing the circuit breaker, sufficient space shall be provided to ensure good air circulation. The spacer between the upper and lower terminals of the circuit breaker must be made of non-magnetic materials to avoid the formation of the magnetic circuit that will affect the use of the product.
- The pivot shall be fixed on the distribution cabinet rack to ensure that the terminal of the circuit breaker shall not bear the weight of the external busbar of the user (this support shall be installed near the terminal).

Cable connection method

The cable connection shall ensure that there is no excessive mechanical force on the circuit breaker terminals. Users can use the cable connection busbar to extend the terminal of the circuit breaker. The cable can be a single-core cable or a multi-core cable. When wiring, it can usually be connected to the busbar according to the following rules: (1) Position the cable lug before inserting the bolt; (2) The cable shall be firmly fixed on the rack of the distribution cabinet.

Wiring method of secondary circuit


The terminal of secondary circuit of circuit breaker adopts screw connection, which is suitable for connecting the single-core or multi-core copper wire with insulating layer, and the cross-sectional area of the wire is 0.5 – 1.5 mm². Before connection, the insulation layer of the wire connection terminal shall be removed with a length of about 6 mm. Screw out the secondary circuit screw by about 2 to 3 mm with a special screwdriver, and then insert the wire and tighten it with a screwdriver. The same terminal of the secondary circuit can insert two wires side by side at the same time on both sides of the screw. The wiring mode is shown in the figure below.

Series Intelligent Universal Circuit Breaker

Attention: The conductor part with insulation removed cannot be exposed outside the secondary circuit to prevent the risk of electric shock.

Busbar wiring method

- In order not to affect the normal use of the circuit breaker, it is recommended to use T2 copper busbar for the user's main circuit wiring busbar. See Table "Rated Current of Circuit Breaker Corresponding to the Cross-sectional Area of External Conductor" for busbar specifications.
- Grade required for the bolt: ≥ 8.8 .
- Too much or too little torque of bolt tightening is not allowed. If the torque is too large, the bolt will slip easily, which will not play the role of fastening; if the torque is too small, it is easy to cause poor contact between the circuit breaker terminal and the user's busbar; they will cause excessive temperature rise. The torque of bolt M10 is 42 N.m; the torque of bolt M12 is 50 N.m.
- After the circuit breaker is installed, the electric gap between different electrified bodies as well as between electrified bodies and other metal parts shall not be less than 20 mm.



Busbar wiring mode of below 1,600 A



Horizontal wiring mode of 1,600 A and above

11 Functions and Characteristics of Accessories



1,000 A Shell Frame Closed Electromagnet

■ Closed electromagnet

When the circuit breaker completes the energy storage operation and is in the normal opening state, the circuit breaker can be quickly closed by remote control of the closing electromagnet.

Working voltage U_s	AC 230 V	AC 400 V	DC 220 V	DC 110 V
Action voltage range	(85–110) % U_s			
Starting current	1.3 A	0.7 A	1.3 A	2.5 A
Pick-up time	≤ 60 ms			
Instantaneous power consumption	300 VA		300 W	



2,000A (and above) Shell Frame Closed Electromagnet



1,000 A Shell Frame Shunt Strip

■ Shunt Strip

When the circuit breaker is in the closing state, the circuit breaker can be quickly disconnected by the remote control of shunt strip.

Working voltage U_s	AC 230 V	AC 400 V	DC 220 V	DC 110 V
Action voltage range	(70–110) % U_s			
Starting current	1.3 A	0.7 A	1.3 A	2.5 A
Pick-up time	≤ 30 ms			
Instantaneous power consumption	300 VA		300 W	



2,000A (and above) Shell Frame Shunt Strip



Phase spacer plate

■ Phase spacer plate

It is vertically installed between the busbars of each phase of the circuit breaker, which is used to enhance the insulation ability between phases of the circuit breaker.

HUW1

Series Intelligent Universal Circuit Breaker



1,000 A Shell Frame Undervoltage Release (overvoltage protection optional)



2,000 A (and above) Shell Frame Undervoltage Release



1,000 A Shell Frame Energy Storage Motor



2,000 A (and above) Shell Frame Energy Storage Motor



1,000 A Shell Frame Auxiliary Switch



2,000 A (and above) Shell Frame Auxiliary Switch



Interruption locking device

■ Undervoltage release

When the undervoltage release is not powered, the circuit breaker cannot be closed;

Working voltage U_e	AC 230 V	AC 400 V
Action voltage range	(35–70) % U_e	
Reliable closing voltage range	(85–110) % U_e	
Voltage range in which the circuit breaker cannot be closed	$\leq 35\%U_e$	
Power consumption	20 VA	
Delay tripping time	Instantaneous, 0.5 s, 1 s, 3 s, 5 s	

Note 1: Within 1/2 delay tripping time, when the working voltage returns to more than 85% U_e , the circuit breaker will not be disconnected;

Note 2: In lightning-prone areas and power grids with unstable power supply voltage, it is recommended to use the undervoltage release with time delay to prevent the circuit breaker from being disconnected due to short-time voltage drop.

■ Energy storage motor

It is used to realize electrical energy storage of the circuit breaker and automatic energy storage again after the circuit breaker is closed, so that the circuit breaker can be closed again immediately after the interruption.

Working voltage U_s	AC 230 V	AC 400 V	DC 220 V	DC 110 V
Working voltage range	(85–110) % U_s			
Energy storage time	(5–7) s			
HUW1-1000 power consumption	75 VA		75 W	
HUW1-2000 power consumption	85 VA		85 W	
HUW1-3200, 4000	110 VA		110 W	
HUW1-6300 power consumption	150 VA		150 W	

Note: Manual energy storage operation can also be performed during circuit breaker maintenance.

■ Auxiliary switch

Default configuration: Conversion Four Normally Open & Four Normally Closed
Other types: Independent four normally open & four normally closed, conversion six normally open & six normally closed, independent five normally open & five normally closed, and independent six normally open & six normally closed

Rated working voltage	AC 230 V	AC 400 V	DC 220 V	DC 110 V
Agreed heating current	6 A			
Rated control capacity	300 VA		60 W	

■ Interruption locking device

Lock the opening button of the circuit breaker in the pressed position, and the circuit breaker cannot be closed at this time.

Note 1: When it's required to pull out the key, you must hold down the opening button and then rotate counterclockwise to pull out the key;

Note 2: The following list of power supply modes is for reference only. The installation and interlock can be performed according to the needs of the actual power supply system on site, or the manufacturer can be consulted for negotiation.

Series Intelligent Universal Circuit Breaker

Mode I: One power supply & one load interlock

Circuit diagram



Possible operation mode




One lock and one key: A circuit breaker is equipped with a lock and a key, and it is not allowed to be closed when locked.


Note 1: 0 indicates that the circuit breaker is open; 1 indicates that the circuit breaker is closed.

Mode II: Two power supplies & one load interlock

Circuit diagram




Possible operation modes



Two locks and one key: Two circuit breakers are equipped with two identical locks and one key, and only one circuit breaker is allowed to be closed.

Mode III: Two power supplies & two load interlocks

Circuit diagram




Possible operation modes



Three locks and two keys: Three circuit breakers are equipped with three identical locks and two keys, and only two circuit breakers are allowed to be closed.

Mode IV: Three power supplies & one load interlock


Circuit diagram



Possible operation modes



Three locks and one key: Three circuit breakers are equipped with three identical locks and one key, and only one circuit breaker is allowed to be closed.



Door Frame

■ Door frame

The door frame is installed on the door of the distribution cabinet where the circuit breaker is installed, which plays a sealing and aesthetic role. The protection level of the door frame can reach IP40 level.



Drawer Operating Padlock

■ Drawer operating padlock

When the main body of the drawer mode circuit breaker is in the "Disconnection" position, the pull-out card board is locked with a padlock. The main body cannot be moved to the "Test" or "Connection" position through cranking after locking. (Users shall prepare padlocks by themselves.)

HUW1

Series Intelligent Universal Circuit Breaker



Relay Module

■ Relay module

Input voltage: DC 24 V

Contact capacity: AC 250 V 10 A; DC 28 V 10 A

When the opening/closing load capacity of the control circuit breaker is large, it needs to be converted by the relay module before control. There are two installation modes: (1) 35 mm standard guide rail, (2) direct installation.



Position Door Interlock

■ Position door interlock

When the main body of the drawer mode circuit breaker is in the "Test" or "Connection" position, the cabinet door is forbidden to open; and when the circuit breaker body is in the "Disconnection" position, the cabinet door is allowed to open.




RCD Residual Current Transformer

■ RCD residual (leakage) current transformer

When the grounding protection is residual current type, a zero-sequence current transformer which is suitable for the protection of small current needs to be added. The signal sampling mode is the sum of phase current vectors.


■ ZT100 grounding transformer

When the grounding mode is the ground current return type (W), the installation dimensions of the additional transformer are shown in the figure below.



■ External N-phase transformer (3P+N mode)


When the controller is 3P+N, the external neutral transformer has the external dimensions as shown in the figure below.



Shell frame	a	b	c	d	e
2,000	61	88	21	87	36
3,200	87	109	31	107	36
4,000	87	109	31	107	36
6,300	87	109	31	107	36

HUW1

Series Intelligent Universal Circuit Breaker




Mechanical Interlock

■ Mechanical Interlock

The cable interlock of two flat circuit breakers or the lever interlock of two stacked circuit breakers.


Cable interlock or lever interlock of two circuit breakers

Two power supplies & one load can only close one circuit breaker




Possible operation modes

1QF	2QF
0	0
0	1
1	0




Cable interlock or lever interlock of three circuit breakers

Three power supplies & one load can only close one circuit breaker




Possible operation modes

1QF	2QF	3QF
1	0	0
0	1	0
0	0	1



Two power supplies & two loads can close two circuit breakers at most



Possible operation modes

1QF	2QF	3QF
0	0	1
1	0	0
0	1	0
1	1	0
0	0	1
1	0	1

Schematic diagram of triple lever interlock

Schematic diagram of triple cable interlock

QF: Circuit breaker

Note: The transition arc at the interlock bending of the cable interlock shall not be less than R120 mm.

HUW1

Series Intelligent Universal Circuit Breaker

13 Order Specification

Unit	Contact person	Tel.	Order quantity	(set)	Order date	
Product model	<input type="checkbox"/> HUW1-1000	<input type="checkbox"/> HUW1-2000 <input type="checkbox"/> HUW1F-2000 <input type="checkbox"/> HUW1PVA-2000	<input type="checkbox"/> HUW1-3200 <input type="checkbox"/> HUW1F-3200 <input type="checkbox"/> HUW1PVA-3200	<input type="checkbox"/> HUW1-4000	<input type="checkbox"/> HUW1-6300	
Rated current	<input type="checkbox"/> 200 <input type="checkbox"/> 400 <input type="checkbox"/> 630 <input type="checkbox"/> 800 <input type="checkbox"/> 1,000	<input type="checkbox"/> 630 <input type="checkbox"/> 800 <input type="checkbox"/> 1,000 <input type="checkbox"/> 1,250 <input type="checkbox"/> 1,600 <input type="checkbox"/> 2,000	<input type="checkbox"/> 2,000 <input type="checkbox"/> 2,500 <input type="checkbox"/> 2,900 <input type="checkbox"/> 3,200	<input type="checkbox"/> 2,500 <input type="checkbox"/> 2,900 <input type="checkbox"/> 3,200 <input type="checkbox"/> 4,000	<input type="checkbox"/> 4,000 <input type="checkbox"/> 5,000 <input type="checkbox"/> 6,300	
Number of poles	<input type="checkbox"/> 3-pole <input type="checkbox"/> 4-pole					
Installation mode	<input type="checkbox"/> Fixed <input type="checkbox"/> Drawer					
Selection of intelligent controller	Type	<input type="checkbox"/> L3 (DIP type, three-section protection) <input type="checkbox"/> L4 (DIP type) <input type="checkbox"/> 2M (digital type) <input type="checkbox"/> 3M (liquid crystal type) <input type="checkbox"/> 2H (digital communication type) <input type="checkbox"/> 3H (liquid crystal communication type)				
	Controller voltage	<input type="checkbox"/> AC 220 V <input type="checkbox"/> AC 380 V <input type="checkbox"/> DC 220 V <input type="checkbox"/> DC 110 V <input type="checkbox"/> DC 24 V				
	Protection parameter settings	Default factory settings: Ir = 1In, Tr=19.2 s; Fixed time Isd=8Ir, Tsd = 0.4 s; Inverse time Isd=4Ir; li = 12In; Ig OFF (open the default value Ig = In, inverse time shear coefficient k = OFF, Tg = 0.4 s)				
		Long time delay protection Ir	Ir = _____ In (selected in 0.4–1.0 or OFF) Tr (1.5Ir) = _____ s (selected in 8, 12.8, 19.2, ..., 1,000)			
		Short-circuit short time delay protection Isd	Isd = _____ Ir (selected in 1.5–15 or OFF) <input type="checkbox"/> Fixed time Tsd = _____ s (selected in 0.1–0.4);			
		Short-circuit instantaneous protection li	li = _____ In (selected in 1.0–20 or OFF), with the maximum of 100 kA			
Grounding protection Ig	Ig = _____ In (selected in 0.2–1.0 or OFF) Tg = _____ s (selected in 0.1–1.0) Inverse time shear coefficient k = _____ (selected in 1.5–6 or OFF)					
Optional functions	<input type="checkbox"/> Voltage measurement <input type="checkbox"/> Frequency measurement <input type="checkbox"/> Voltage imbalance rate measurement <input type="checkbox"/> Phase sequence detection <input type="checkbox"/> Power measurement <input type="checkbox"/> Power factor measurement <input type="checkbox"/> Temperature control monitor (H type) <input type="checkbox"/> Electric energy measurement <input type="checkbox"/> ZSI function <input type="checkbox"/> Harmonic measurement <input type="checkbox"/> Overvoltage protection <input type="checkbox"/> Undervoltage protection <input type="checkbox"/> Voltage imbalance protection <input type="checkbox"/> Reclosing (H type) <input type="checkbox"/> Overfrequency protection <input type="checkbox"/> Underfrequency protection <input type="checkbox"/> Phase sequence protection <input type="checkbox"/> Reverse power protection <input type="checkbox"/> Demand value protection <input type="checkbox"/> Ground current type grounding protection <input type="checkbox"/> Residual action current protection <input type="checkbox"/> Load monitoring function <input type="checkbox"/> Neutral line protection <input type="checkbox"/> Demand value measurement (current and power) <input type="checkbox"/> DI input function <input type="checkbox"/> DO output function <input type="checkbox"/> Communication function: Modbus protocol (default, available for H type)					
Standard configuration accessories	Closed electromagnet	<input type="checkbox"/> AC 220 V <input type="checkbox"/> AC 380 V <input type="checkbox"/> DC 220 V <input type="checkbox"/> DC 110 V				
	Shunt strip	<input type="checkbox"/> AC 220 V <input type="checkbox"/> AC 380 V <input type="checkbox"/> DC 220 V <input type="checkbox"/> DC 110 V				
	Energy storage motor	<input type="checkbox"/> AC 220 V <input type="checkbox"/> AC 380 V <input type="checkbox"/> DC 220 V <input type="checkbox"/> DC 110 V				
	Auxiliary switch	<input type="checkbox"/> Conversion four normally open & four normally closed <input type="checkbox"/> Independent four normally open & four normally closed <input type="checkbox"/> Conversion six normally open & six normally closed <input type="checkbox"/> Independent six normally open & six normally closed <input type="checkbox"/> Special form (Note: HUW1-1000 only has two types: conversion four normally open & four normally closed and conversion six normally open & six normally closed)				
Optional accessories	Undervoltage release	<input type="checkbox"/> AC220V <input type="checkbox"/> AC380V <input type="checkbox"/> Instantaneous (default) <input type="checkbox"/> 0.5 s <input type="checkbox"/> 1 s <input type="checkbox"/> 3 s <input type="checkbox"/> 5 s				
	Opening locking device	<input type="checkbox"/> One circuit breaker with a lock and a key <input type="checkbox"/> Two circuit breakers with two locks and a key <input type="checkbox"/> Three circuit breakers with three locks and two keys <input type="checkbox"/> Special form (customized according to user's requirements)				
	Mechanical Interlock	<input type="checkbox"/> Two circuit breakers <input type="checkbox"/> Lever interlock (up and down interlock) <input type="checkbox"/> Cable interlock <input type="checkbox"/> Three circuit breakers <input type="checkbox"/> Lever interlock (up and down interlock) <input type="checkbox"/> Cable interlock (Note: Two closing & one opening or one closing & two opening)				
	Dual power controller	<input type="checkbox"/> Two power supplies <input type="checkbox"/> Three power supplies <input type="checkbox"/> Two power supplies+bus coupler (Note: Please indicate if fire control or communication functions are required)				
	Others	<input type="checkbox"/> Residual current transformer <input type="checkbox"/> Neutral current transformer <input type="checkbox"/> Grounding transformer <input type="checkbox"/> Power adapter <input type="checkbox"/> Door interlock <input type="checkbox"/> Relay module <input type="checkbox"/> Protocol conversion module (Profibus-DP, DeviceNet) <input type="checkbox"/> Electric three-position indication of drawer seat <input type="checkbox"/> Energy storage ready indication <input type="checkbox"/> Opening/closing button lock <input type="checkbox"/> Secondary terminal cover <input type="checkbox"/> Counter				

Note 1: If the user has other special requirements when ordering, please consult with the manufacturer in advance;

Note 2: The cost of the circuit breaker's optional functions and accessories are not included in its standard configuration, and the cost will be calculated separately.

HUW1

Series Intelligent Universal Circuit Breaker



Certificate

Name: Intelligent Universal Circuit
Breaker

Model: HUW1 Series

Inspector:



Date: See product label or QR
code

The product meets the requirements of GB/T
14048.2 and is allowed to leave the factory after
passing the inspection.

环宇高科有限公司
HUANYU HIGH-TECH CO., LTD.



HUANYU HIGH-TECH CO., LTD.

Address: Wenzhou Bridge Industrial Zone, Yueqing City,

Zhejiang Province

Tel.: 0577-62889999

Fax: 0577-62885588

Postal code: 325603

As products are constantly updated, the above information is
subject to the confirmation by the technical department of our
company

National unified
customer service
hotline

400-887-5757

<http://www.huyu.com.cn>